

To install, just flex the tray at the crease and position it into the eaves between the rafters from inside the loft, making sure the ridges face the towards the underlay. You need to push the insulation up to the tray to hold it in place and check that the insulation material does not touch the roofing underlay. If you need wider spacing the trays can be clipped together to provide 10mm airflow

Details	1			1
REF	AIR435RF		MANUFACTURING PROCESS	Injection moulded
BOX SIZE (MM)	E 80 x 410 x 640		MATERIAL	R-PET
PALLET SIZE (M)	1 X 1.2 X 2			
FREE AREA	100cm ² per metre run when installed between rafters at eaves level		ASSOCIATED PRODUCTS	
PACKING	Product per box = 50, Boxes per pallet = 50			
WEIGHT	Product =60g, Box =3.8kg, pallet =205kg		COLOUR	BLACK
References		BRE : DIGEST 262/270 BSI : BS5250 DOE : Building Regs F2 NHBC : Good Practice Guide NHBC : Standards 7.2		
Airfl	ow(Nic	oll Ventilators) Limited, Unit 15 Queensway, Telephone: 01425 611547 FAX:014 Made in	25 638912 e-mail:sales@	
		ntinuous development Airflow (Nicoll Ventilators) Limit		od the specification without notice